REPORT DOCUMENTATION PAGE

Form Approved OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of

	B control number. PLEASE DO NOT RETURN YOUR FORM TO THE	ABOVE ADDRESS.
1. REPORT DATE (DD-MM-YYYY)	2. TYPE REPORT	3. DATES COVERED (From - To)
25-09-2007	Conference Briefing Charts	01-10-2006 to 10-09-2007
4. TITLE AND SUBTITLE		5a. CONTRACT NUMBER
Two Cell Josephson Junction Q	tubits (Briefing Charts)	5b. GRANT NUMBER
		5c. PROGRAM ELEMENT NUMBER
		61102F
6. AUTHOR(S)	5d. PROJECT NUMBER	
		2304
Stanford P. Yukon	5e. TASK NUMBER	
		HE
		5f. WORK UNIT NUMBER
		03
7. PERFORMING ORGANIZATION NA	ME(S) AND ADDRESS(ES)	8. PERFORMING ORGANIZATION REPORT
AFRL/SNHE		
80 Scott Drive		
Hanscom AFB MA 01731		
9. SPONSORING / MONITORING AGE Electromagnetics Technology D	10. SPONSOR/MONITOR'S ACRONYM(S)	
Sensors Directorate	AFRL-SN-HS	
Air Force Research Laboratory		74 142 314 110
80 Scott Drive	11. SPONSOR/MONITOR'S REPORT	
Hanscom AFB MA 01731-2909		NUMBER(S)
Haliscolli AFB WA 01731-2909		AFRL-SN-HS-TP-2007-0009

12. DISTRIBUTION / AVAILABILITY STATEMENT

DISTRIBUTION A. Approved for public release; distribution unlimited.

13. SUPPLEMENTARY NOTES

Presented at Frontiers of Josephson Physics and Nanoscience 07, Palinuro, Italy, 25-28 Sep 2007. This is a work of the U.S. Government and is not subject to copyright protection in the United States. ESC/PA Clearance Number: ESC 07-1112, dated 21 Sep 07.

14. ABSTRACT

The basic two cell qubit contains four Josephson junctions, two residing on the conductor common to the two cell loops, and one on each loop's perimeter. In the limit of zero inductance the qubit potential is described by two phase variables and two orthogonal external magnetic flux parameters (the symmetric and antisymmetric combinations of external flux). The barrier height of the effective double well potential is controlled by the symmetric external flux and the potential tilt by the antisymmetric flux. We will discuss the effect of non-zero inductance and defects on the qubit energy levels, circulating currents, matrix elements, and on the relaxation and phase decoherence times.

15. SUBJECT TERMS

Josephson junction, qubits, single qubit gates, Molmer Sorensen gates, decoherence, LC bus

16. SECURITY CLASSIFICATION OF:		17.LIMITATION OF ABSTRACT	18.NUMBER OF PAGES	19a. NAME OF RESPONSIBLE PERSON Stanford P. Yukon	
a. REPORT	b. ABSTRACT	c. THIS PAGE			19b. TELEPHONE NUMBER (include area code)
Unclassified	Unclassified	Unclassified	SAR	28	N/A

Standard Form 298 (Rev. 8-98) Prescribed by ANSI Std. Z39.18




Two Cell Josephson Junction Qubits

Hanscom AFB, Massachusetts 01731 Air Force Research Laboratory/SNHE Stanford P. Yukon

Outline of Talk

- Two Cell Josephson Junction Qubit
- Molmer Sorensen Bichromatic Gates
- Tavis Cummings Hamiltonian
- Forming a Network of LC Buses
- **Experimental Developments**
- Conclusions

Potential $V(\theta, \psi)$ for a Two Cell Qubit



$$\Psi = \sqrt{N}e^{i\varphi}$$

$$I = I_C \sin(\phi)$$

$$\nu = \dot{\phi}(\Phi_0 / 2\pi)$$

$$U = \{1 - \cos(\phi)\}$$



$$\zeta_1 - \zeta_2 - \zeta_3 = \phi_L$$

$$\zeta_2 - \zeta_1 + \zeta_4 = \phi_R$$

$$\phi_{
m L} \qquad \zeta_2 - \zeta_1 + \zeta_4 = \phi_{
m R}$$

 $V(\theta, \psi) = -2\{\cos(\theta)\cos(\psi) + \cos(\phi)\cos(2\psi - \phi)\}$

$$\phi_{\rm a} = (\phi_{\rm L} - \phi_{\rm R})/2,$$


$$\theta = (\zeta_1 + \zeta_2)/2,$$

$$\phi_{\rm s} = (\phi_{\rm L} + \phi_{\rm R})/2,$$


$$V = (\zeta_1 + \zeta_2)/2,$$

 $\Psi = (\zeta_1 - \zeta_2)/2.$

Contour Plot of the 2D Potential for the 2 Cell Qubit



Energy Levels for V(0, |)



$$-\frac{1}{2m_{_{\psi}}}\frac{\partial^{2}\Psi(\psi)}{\partial\psi^{2}} - [2\cos(\psi) - r\cos(2\psi)]\Psi(\psi) = \frac{E_{i}}{E_{J}}\Psi(\psi)$$

Circulating Current Patterns


$$J_{3,4}^{\ket{0}} = ra{0}J_{C3,4}\sin{\mathcal{\zeta}_{3,4}}\ket{0} = \mp j\kappa_0, \qquad J_{3,4}^{\ket{1}} = ra{1}J_{C3,4}\sin{\mathcal{\zeta}_{3,4}}\ket{1} = \mp j\kappa_1$$


$$J_3^{|-\rangle} = -rac{1}{2}j(\mathcal{K}_0 + \mathcal{K}_1) - j\,\mathcal{K}_{01}$$

$$J_3^{-} = -\frac{1}{2}j(K_0 + K_1) - jK_0$$
 $J_3^{-} = +\frac{1}{2}j(K_0 + K_1) - jK_0$


 $J_3^{+
angle} = -rac{1}{2}j(\mathcal{K}_0 + \mathcal{K}_1) + j\,\mathcal{K}_{01}, \ J_4^{+
angle} = +rac{1}{2}j(\mathcal{K}_0 + \mathcal{K}_1) + j\,\mathcal{K}_{01},$

$$J_3^{|-\rangle} = -rac{1}{2}j(\mathcal{K}_0 + \mathcal{K}_1) - j\mathcal{K}_{01} \ J_4^{|-\rangle} = +rac{1}{2}j(\mathcal{K}_0 + \mathcal{K}_1) - j\mathcal{K}_{01}.$$






Resonant LC Bus Symmetrically Coupled to Qubit Pairs




Two Cell Qubit Interactions

First order interactions: yield z and x axis qubit rotations





Second order interactions mediated by an off resonance LC bus




yield $H_{effective}^{(i,j)} = \Omega_P(\sigma_+^{(i)}\sigma_-^{(j)} + \sigma_-^{(i)}\sigma_+^{(j)})$, an XY spin Hamiltonian interaction

Initializing and Measuring Qubit States







Logical Qubits for Decoherence Free Subspaces

The bus-qubit interaction Hamiltonian can be written as

$$H_{\text{int}}^{(i)} = \Omega^{(i)} f(t) \sigma_x^{(i)} (a + a^+)$$

where f(t) is the pulse envelope, and

$$\Omega^{(i)} = [-r \tan(\phi_s^0) \delta_a^{(i)} s_{10} \sqrt{\hbar \omega_{LC} L/2} \mu(L^{(i)}/2L)].$$

 $\frac{1}{2}r(c_{00}-c_{11})\{J_0[f(t)\delta_a^{(i)}]-1\}\sigma_z^{(i)}\equiv \delta\!\Omega^{(i)}\sigma_z^{(i)}.$ Gate phase errors An unwanted concomitant that will induce gate phase errors is

using either encoded logical product state qubits or Bell state qubits and fluctuations of symmetric flux $\sin(\delta\phi_s^{ext})\sigma_{z}^{(i)}$ can be nulled by

$$|0_L\rangle = |01\rangle \equiv |0\rangle \otimes |1\rangle, \quad |1_L\rangle = |10\rangle \equiv |1\rangle \otimes |0\rangle$$

$$\left| \tilde{0}_L \right\rangle = \left(\left| 01 \right\rangle + \left| 10 \right\rangle \right) / \sqrt{2}, \quad \left| \tilde{1}_L \right\rangle = \left(\left| 01 \right\rangle - \left| 10 \right\rangle \right) / \sqrt{2}. \quad \mathsf{FC}$$

For either type

$$\left[\partial \Omega^{(i)} \hat{\sigma}_z^{(i)} + \partial \Omega^{(i+1)} \hat{\sigma}_z^{(i+1)} \right] \left\{ \begin{vmatrix} 10 \\ |01 \rangle \end{vmatrix} = 0 \quad \text{if } \partial \Omega^{(i)} = \partial \Omega^{(i+1)} \right\}$$

Matrix Elements of Product and Bell Logical Qubits

Bell State qubits have the property that their eigen energies are $\left\langle \tilde{0}_{\scriptscriptstyle L} \left| H^{\scriptscriptstyle (1)} + H^{\scriptscriptstyle (2)} \left| \tilde{0}_{\scriptscriptstyle L} \right\rangle = \left\langle \tilde{1}_{\scriptscriptstyle L} \left| H^{\scriptscriptstyle (1)} + H^{\scriptscriptstyle (2)} \left| \tilde{1}_{\scriptscriptstyle L} \right\rangle = \right. \right.$ exactly equal

$$\left[\left\langle 0 \right| H^{(1)} \left| 0 \right\rangle + \left\langle 1 \right| H^{(1)} \left| 1 \right\rangle + \left\langle 0 \right| H^{(2)} \left| 0 \right\rangle + \left\langle 1 \right| H^{(2)} \left| 1 \right\rangle \right]$$

whereas $t_r = \left\langle \tilde{0}_L \left| H^{(1)} + H^{(2)} \left| \tilde{1}_L \right\rangle = (\varepsilon_1 - \varepsilon_0)^{(1)} - (\varepsilon_1 - \varepsilon_0)^{(2)}$ if not equal to zero will lead to tunneling between the two states. Transforming to a basis where $t_r = 0$ yields product states where


$$\langle 0_L | H^{(1)} + H^{(2)} | 0_L \rangle - \langle 1_L | H^{(1)} + H^{(2)} | 1_L \rangle = (\mathcal{E}_1 - \mathcal{E}_0)^{(2)} - (\mathcal{E}_1 - \mathcal{E}_0)^{(1)}.$$

 $(\varepsilon_1 - \varepsilon_0)^{(i)}$ and $(\varepsilon_1 - \varepsilon_0)^{(j)}$ for each logical qubit (j = i + 1) than For a QC to have zero tunneling among entangled states it should be much simpler to require the pairwise equality of global equality for all physical qubits.


Mølmer Sørensen(MS) Gate

$$\Omega_{eff} = (2/\hbar) \sum_{m} \frac{\langle 10; n | H_{\text{int}} | m \rangle \langle m | H_{\text{int}} | 01 \rangle}{E_{m} - (E_{01} + \hbar \omega_{m})} = -\frac{\Omega^{2}}{\omega_{osc} - \delta}$$

 $\omega = \omega_{10} \pm \delta$ Bichromatic excitation



Mølmer Sørensen Gate II



$$V(t) \cong -\sqrt{2}\Omega J_x(\vec{\phi})[x(\cos(\omega_{LC} - \delta)t + p(\sin(\omega_{LC} - \delta)t)]$$

$$= J_x(\vec{\phi})[xf(t) + pg(t)]$$

The exact solution for iU(t)=VU(t) is

$$U(t) = e^{-iA(t)J_x^2} e^{-iF(t)J_xx} e^{-iG(t)J_xp}$$

$$F(t) = \int_0^t f(\tau) d\tau = -\frac{\sqrt{2\Omega}}{(\omega_{LC} - \delta)} \sin[(\omega_{LC} - \delta)t],$$

$$G(t) = \int_0^t g(\tau) d\tau = -\frac{\sqrt{2\Omega}}{(\omega_{LC} - \delta)} \{1 - \cos[(\omega_{LC} - \delta)t]\}, \quad A(t) = -\int_0^t F(\tau)g(\tau) d\tau = -\frac{\Omega^2}{(\omega_{LC} - \delta)} \{t - \frac{\sin(\omega_{LC} - \delta)t}{2(\omega_{LC} - \delta)}\}$$

U(t) performs translations in xp phase space entangled with J_{x}

$$(x,p) \to (x+J_xG(t), p-J_xF(t))$$
 $J_x = \frac{1}{2}\sum_{-1}[e^{i\phi_i}\sigma_+^i + e^{-i\phi_i}\sigma_-^i]$

Single Qubit MS Gate Constraints

$$U(t) = e^{-iA(t)J_x^2} e^{-iF(t)J_xx} e^{-iG(t)J_xp}$$

For the oscillator variables to return to their pre-gate values

$$F(t) = -\frac{\sqrt{2\Omega}}{(\omega_{LC} - \delta)} \sin[(\omega_{LC} - \delta)t] = 0$$

$$G(t) = -\frac{\sqrt{2\Omega}}{(\omega_{LC} - \delta)} \{1 - \cos[(\omega_{LC} - \delta)t] = 0\}$$

$$A(t_K) \text{ is then given by }$$

$$A(t_K) = -\frac{\Omega^2}{(\omega_{LC} - \delta)} t_K$$

These may be combined to give the required pulse time as a function of $A(t_K), \omega_{LC}, \delta$, and Ω as

$$t_K = \sqrt{-2\pi K A}/\Omega$$
 also $\delta = \omega_{LC} \pm 2\Omega (A_{\pi/2}/A)^{1/2}$

2 & 4 Qubit Mølmer Sørensen Operators

$$J_x(ec{\phi}) = rac{1}{2} \sum_i \left[e^{i\phi_i} \hat{\sigma}^i_+ + e^{-i\phi_i} \hat{\sigma}^i_-
ight] \lambda_i, \quad \lambda_i = (\Omega_i / \Omega)$$
 $2J_x^2 = rac{1}{2} (\lambda_1^2 + \lambda_2^2) egin{bmatrix} 1 \ 1 \ 1 \end{bmatrix} + \lambda_1 \lambda_2 egin{bmatrix} e^{-i(\phi_1 + \phi_2)} \ e^{-i(\phi_1 - \phi_2)} \ e^{-i(\phi_1 - \phi_2)} \ \end{bmatrix}$

Single logical qubit operators

$$\overline{X} = 2J_x^2(\phi_{1,2} = 0) = \frac{1}{2}(\lambda_1^2 + \lambda_2^2)\hat{\mathbf{1}} + \lambda_1 \lambda_2 \hat{\sigma}_x^{(1)} \hat{\sigma}_x^{(2)},$$

$$\overline{Y} = 2J_x^2(\phi_1 = 0, \ \phi_2 = \frac{1}{2}\pi) = \frac{1}{2}(\lambda_1^2 + \lambda_2^2)\hat{\mathbf{1}} - \lambda_1 \lambda_2 \hat{\sigma}_x^{(1)} \hat{\sigma}_y^{(2)}$$

Two logical

$$\overline{XX} = 2J_x^2(\phi_{1,2,3,4} = 0) = \frac{1}{2} \sum_{i=1}^4 \lambda_i^2 \hat{I} + \sum_{i=1}^4 \sum_{j=i+1}^4 \lambda_i^2 \hat{\mathcal{J}}_j \hat{\mathcal{O}}_x^{(i)} \hat{\mathcal{O}}_x^{(j)}$$

qubit operators

$$\lambda_j = 1 \rightarrow \exp(i\frac{\pi}{4}\frac{\overline{XX}}{XX}) = e^{-i\frac{\pi}{4}} \exp[-i\frac{\pi}{4}\hat{\sigma}_x^{(1)}\hat{\sigma}_x^{(2)}\hat{\sigma}_x^{(3)}\hat{\sigma}_x^{(4)}].$$

One and Two Logical Qubit Mølmer Sørensen Gates

Product logical qubits

Bell state logical qubits

$$|0_L\rangle = |01\rangle, |1_L\rangle = |10\rangle$$

$$\left| \tilde{0}_{\scriptscriptstyle L}, \tilde{1}_{\scriptscriptstyle L} \right\rangle = \frac{1}{\sqrt{2}} \left\{ \left| 0_{\scriptscriptstyle L} \right\rangle \pm \left| 1_{\scriptscriptstyle L} \right\rangle \right\}$$

$$\sigma_{Lx} = \sigma_x^{(1)} \sigma_x^{(2)}$$

$$\tilde{\sigma}_{Lz} = \sigma_x^{(1)} \sigma_x^{(2)}$$
 $\tilde{\sigma}_{Ly} = -\sigma_y^{(1)} \sigma_x^{(2)}$

$$\sigma_{Ly} = \sigma_y^{(1)} \sigma_x^{(2)}$$
$$\sigma_{Lz} = -i \sigma_{Lx} \sigma_{Ly}$$

$$\tilde{\sigma}_{Lx} = -i\, ilde{\sigma}_{Lx}\, ilde{\sigma}_{Ly}$$

$$U_{\scriptscriptstyle CN}^{I,II}= ilde{U}_{\scriptscriptstyle CN}^{II,I}$$

$$ilde{U}_{\scriptscriptstyle C\!N}^{I,I\!I}= ilde{H}^{I\!I}\, ilde{U}_{\scriptscriptstyle C\!Z}^{I,I\!I}\, ilde{H}^{I\!I}$$

 $ilde{U}_{CZ}^{I,II} = \sqrt{i}e^{i ilde{\sigma}_z^{(I)} ilde{\sigma}_z^{(I)}\pi/4}e^{-i ilde{\sigma}_z^{(I)}\pi/4}e^{-i ilde{\sigma}_z^{(II)}\pi/4}$

$$U_{CZ}^{I,II}=H^{II}U_{CN}^{I,II}H^{II}$$

where
$$H_L= ilde{H}_L=(-i)e^{-i ilde{\sigma}_{Ly}\pi/4}e^{+i ilde{\sigma}_{Lz}\pi/2}$$

Effect of Differing Rabi Frequencies on MS Gates

First express $\Omega_i/\Omega=\lambda_i=1+\gamma_i$. In general there will be terms like $\gamma^{(1)}\gamma^{(3)}\sigma_x^{(1)}\sigma_x^{(3)}$. An average $\Omega_x=\Omega$ can be defined for which $\gamma^{(1)}+\gamma^{(2)}+\gamma^{(3)}+\gamma^{(4)}=0$. If you demand that $\gamma^{(1)}+\gamma^{(2)}=\gamma=-\gamma^{(3)}-\gamma^{(4)}$, only $\sigma_x^{(1)}\sigma_x^{(2)}$ and $\sigma_x^{(3)}\sigma_x^{(4)}$ terms survive.

$$\exp(it XX) = \exp[-i\Omega_{av}t(1-\gamma)\hat{\sigma}_{x}^{(1)}\hat{\sigma}_{x}^{(2)}\hat{\sigma}_{x}^{(3)}\hat{\sigma}_{x}^{(4)}/2] \\ \times \exp[it(2\gamma + \gamma^{2})\hat{\sigma}_{x}^{(1)}\hat{\sigma}_{x}^{(2)}/2] \exp[-it(2\gamma - \gamma^{2})\hat{\sigma}_{x}^{(3)}\hat{\sigma}_{x}^{(4)}/2]$$

The exact $\tilde{U}_{cz}^{(1,2),(3,4)}$ gate can then be carried out with two overlapping microwave pulses:

$$\leftarrow t^{(1,2)}=z^{-1}(s/2)(204j.7j^2)$$
 $\Omega^{(1,2)} \geq \Omega^{(3,4)}$

$$\leftarrow t^{(1,2)} = T^{-1}(s/2)(104j.6j^2) + t^{(1,2)} = T^{-1}(s/2)(2.4j.7j^2) - t^{(1,2)} = T^{-1}(s/2)(2.4j.7j^2)$$

Critical Current and Cell Geometry Defects

$$\Delta V = -\{2j\sin\phi_{a,geom}\cos\phi_s^0 + 2\Delta j\cos\phi_{a,geom}\sin\phi_s^0\}\sin2\psi - 2\Delta J\sin\theta\sin\psi$$

$$=-\kappa_{defect} \sin 2\psi - 2\Delta J \sin \theta \sin \psi = \Delta V^a$$


trim flux so that $\phi_a^0 = \phi_{a,geom} + \phi_{a,trim}$ satisfies ΔV^a may be nulled by adding a small $\tan \phi_a^0 = -(\Delta j/j) \tan \phi_s^0 \implies {\Delta V}^a = 0,$

 $J_{3,4}^{|0,1\rangle} o J_{3,4}^{|0,1\rangle} imes (1-(\Delta j/j)^2)$, figure 8 currents stay zero, $r o r/\cos\phi_a^0$


If $\phi_{a,trim}$ is not added, $H_0 + \Delta V_a$ can be diagonalized by a unitary rotation to a new basis but there will be a non zero figure 8 current $\kappa_{0,1}j(\Delta j/j + \tan \phi_{a,geom}/\tan \phi_s^0)$. At $r=r^*$, $\kappa_{0,1}(\Delta j/j) \approx 10^4$.

unperturbed states|0
angle and |1
angle will pick up small admixtures of $|1_{ heta}
angle |1_{ heta}
angle$ The effect of ΔV^b can be estimated by perturbation theory. The and $|1_{ heta}
angle |0_{w}
angle$ respectively, but this will not lead to figure 8 currents;


Numerical Solution for iSWAP Gate



CNOT and SWAP Gates from iSwap




Five Qubit Error Correcting Code




Forming a CN Gate Across a Network

$$ilde{U}_{CN}^{I,II} = \sqrt{i}e^{-i ilde{\sigma}_{y}^{(II)}\pi/4} e^{-i ilde{\sigma}_{z}^{(I)}\pi/4} e^{i ilde{\sigma}_{z}^{(II)}\pi/4} e^{-i ilde{\sigma}_{z}^$$



For $\tilde{U}_{CN}^{A,B}$ need a sequence of CN gates (A, \mathfrak{t}_{12}),(\mathfrak{t}_{12} , \mathfrak{t}_{23}),(\mathfrak{t}_{23} , B) and a sequence (A, \mathfrak{t}_{12}), $(\mathfrak{t}_{12}$, \mathfrak{t}_{23}) to reset the transfer qubits. For every transfer qubit involved, one less single qubit gate $ilde{\mathcal{O}}_{ec{J}}$ is needed, reducing the total gate time by $T_{1/2} = \nu_{Rabi}^{-1}/2$ for each instance. Thus the time needed for ($t_{12},\,t_{23}$) is $3T_{1/2}.$

Coupling Buses into a Network



Coupling buses into a network using transfer qubits enables:

- Simultaneous (intra-bus) two qubit gates
- Scaling to arbitrary qubit numbers
- Teletransport of qubits via entangled qubit pairs

Two Readout Squid Circuit




Figure 9: Schematic circuit of a qubit inductively coupled to a readout dc-SQUID. Each SQUID is shunted by two 5 pF capacitor. The current bias and voltage measurements are performed via 150 Ohm resistor on each lead.




Figure 8: Micro design of inductively coupled qubit and two SQUID.

Gradiometer Coupling to SQUID




Figure 12: Schematic circuit of a qubit coupled to a readout dc-SQUID via a gradiometric loop. The SQUID is asymmetric.




Figure 13: The actual design of gradiometric coupling between a qubit and a SQUID

Conclusions

Using logical prism qubit pairs and MS gates it is possible to carry out all necessary gates for quantum computation:

- to obtain $\mathcal{E}_{10}^{(i)} = \mathcal{E}_{10}^{(i+1)}$ can enable global phase coherence (no time 1) Pairwise adjustment of qubit transition frequencies (by $\phi_{\rm c}^{0(i)}$) evolution or decay of entangled states).
- adjusting $\delta_a^{(i)}$) enables MS gates to be carried out without phase 2) Pairwise adjustment of Rabi frequencies $\Omega_{Rabi}^{(i)} = \Omega_{Rabi}^{(i+1)}$ (by errors. All two qubit gates can be carried out when timing is adjusted to compensate for $\Omega_{Rabi}^{(A)} \neq \Omega_{Rabi}^{(B)}$.
- there are no figure 8 currents to interact with SQUID gradiometer detectors; DFS properties are preserved even during MS gates. 3) Only qubit perimeter currents exist during a computation;
- 4) If the resonant frequencies of adjacent buses differ by \square $4\Omega_{Rabi}$ network by employing transfer qubits and chaining CN gates. Molmer Sorensen gates can be carried out across an open